


QUANTUM®

Blu BL30PTs



Quantum BL30PTs Spinning Reel Part List

Key #	Description	Qty	Part No.	Key #	Description	Qty	Part No.
1	Drag Knob Assembly	1	BAA332-06	31	Clutch Bearing Adapter	1	BAA190-01
2	Retainer Ring	1	BAA038-01	32	Clutch Unit	1	BAA363-01
4	Drag Washer "B"	3	BAA033-01	33	Pinion Ball Bearing	1	BAA028-01
5	Drag Washer "D"	2	BAA080-01	34	Pinion Bushing	2	BAA213-01
6	Drag Washer "A"	1	BAA081-01	35	Pinion	1	BAA011-01
7	Spool Assembly	1	CAA320-51	36	Stopper Cam	1	BAA090-02
8	Rotor Nut Lock Screw	1	BAA094-01	37	Clutch Spring	1	BAA216-01
9	Spool Adjust Washer	2	BAA030-01	38	Stopper Cam Spring	1	BAA089-01
10	Click Gear	1	BAA037-01	39	Stopper Lever	1	BAA059-03
11	Rotor Nut	1	BAA006-01	40	Stopper Lever Screw	1	BAA135-01
12	Main Shaft	1	BAA015-01	41	Handle Screw Assembly	1	BAA354-03
13	Arm Lever Screw	2	BAA042-01	42	Rear Cap Screw (Front)	1	CAA168-01
14	Rotor	1	CAA009-07	43	Body Assembly	1	BAA301-08
15	Kick Lever	1	CAA019-01	44	Body Rear Cap	1	BAA140-02
16	Actuator	1	BAA031-01	45	Tapping Screw	1	CAA094-01
17	Actuator Spring	1	BAA022-01	46	Main Shaft Screw	1	BAA100-01
18	Arm Lever Cover	1	CAA087-01	47	O/S Slider	1	BAA025-02
19	Arm Lever Cover Screw	2	BAA077-01	48	O/S Gear	1	BAA053-02
20	Line Roller Screw	1	BAA108-01	49	O/S Gear Ball Bearing	1	BAA158-01
21	Arm Lever	1	BAA007-07	50	O/S Slider Retainer	1	BAA078-01
22	Line Roller Collar	1	CAA102-01	51	Body Ball Bearing	1	BAA157-01
23	Line Roller Washer	1	BAA102-01	52	Drive Gear	1	BAA012-02
24	Line Roller	1	BAA004-04	53	Drive Gear Adjust Wahser	1	BAA105-01
25	Line Roller Ball Bearing	1	GH202-01	54	Side Cover Ball Bearing	1	CAA157-01
26	Bail Assembly	1	CAA347-03	55	Side Cover Assembly	1	BAA323-06
27	Rotor Adjust Washer	2	BAA110-01	56	Side Cover Screw	3	BAA085-01
28	Tapping Screw (Flat head)	3	CAA057-01	57	Side Cover Screw (Flat head)	1	BAA057-01
29	Clutch Stack Retainer	1	CAA040-01	58	Handle Assembly	1	BAA418-06
30	Clutch Retainer Ball Bearing	1	UK028-01				