


QUANTUM[®]

Energy E770PTs

For parts and service

call toll free: 1-888-404-1119

www.mikesreelrepair.com



| Quantum Energy Salt Water E770PTs Part List | | | | | |
|---|--|-----------|---------|--|-----------|
| Key No. | Description | E770PTs | Key No. | Description | E770PTs |
| 1 | Palm Side Cover Kit include 1A - Palm Side Cover Assembly 1B - Centrifugal Dial Washer 1C - Centrifugal Dial Assembly 1D - Centrifugal Dial Friction Ring 1E - Centrifugal Dial Spring 1F - Spool Cover 1G - Spool Cover Screw 1H - Brake Ring Assembly 1J - Brake Ring Slider Spring 1K - Brake Ring Retainer Screw 2 - Spool Tension Shim 3 - Spool Shaft Ball Bearing (Palm) 4 - Clip Ring | UX4023-05 | 28 | Worm Shaft Guide | UX016-01 |
| 2 | Spool Tension Shim | QW032-04 | 29 | Line Guide Carrier | UX047-01 |
| 3 | Spool Shaft Ball Bearing (Palm) | QV017-02 | 30 | Line Guide Carrier Screw | ZW007-02 |
| 4 | Clip Ring | HV080-01 | 31 | Side Cover Locking Lever | YX119-02 |
| 5 | Spool Assembly | UX321-08 | 32 | Side Cover Locking Lever Spring | ZW096-01 |
| 6 | Clip Ring | EX080-01 | 33 | Hood Screw | HX107-02 |
| 7 | Spool Shaft Ball Bearing (Gear) | EX017-03 | 34 | Hood | UX027-04 |
| 8 | Gear Side Cover Screw - B | QW053-03 | 35 | Front Support | UX099-03 |
| 9 | E-Clip | NX092-01 | 36 | Front Support Screw | HX107-02 |
| 10 | Frame | UX001-07 | 37 | Worm Shaft Bushing (Gear) | HV068-01 |
| 11 | Thumb Bar | UX009-01 | 38 | O/S Pinion Gear Washer | EX035-01 |
| 12 | Kick Lever Spring | GX097-01 | 39 | O/S Pinion Gear | UX085-01 |
| 13 | Kick Lever | UX077-01 | 40 | E-Clip | NX090-01 |
| 14 | Release Slider | UX039-01 | 41 | Crank Shaft Bearing - Lower | SW017-01 |
| 15 | Thumb Bar Screw | ZW053-01 | 42 | E-Clip | QW120-01 |
| 16 | Release Slider Spring | CX104-01 | 43 | Crank Shaft Retainer | UX002-01 |
| 17 | Release Slider Guide Pin | UX102-02 | 44 | Crank Shaft Retainer Screw | JX107-02 |
| 18 | Pinion Yoke | GX025-01 | 45 | Crank Shaft | UX008-01 |
| 19 | Yoke Spring | GX040-01 | 46 | O/S Drive Gear | UX112-01 |
| 20 | Gear Kit include 20A - Pinion Gear Assembly 20B - Drive Gear | VX4011-01 | 47 | Trip Ratchet | EX083-01 |
| 21 | Stabilizer Bar - B | UX061-02 | 48 | Trip Ratchet Washer | QW111-01 |
| 22 | Stabilizer Bar - A | VX061-01 | 49 | Drag Disc | UX059-01 |
| 23 | Gear Side Cover Screw - A | BV123-03 | 50 | Drag Key Washer | UX045-01 |
| 24 | E-Clip | NX092-01 | 51 | Link | UX036-01 |
| 25 | Bearing Retainer | CX067-01 | 52 | One Way Bearing Sleeve | UX052-01 |
| 26 | Worm Shaft Ball Bearing | XX117-01 | 53 | Gear Side Cover Assembly | UX324-07 |
| 27 | Worm Shaft Kit Include 27A - Worm Shaft 27B - Line Guide Pawl 27C - Carrier Washer | HV4072-02 | 54 | Tension Knob O-Ring | QW101-01 |
| | | | 55 | Tension Knob Ball Bearing | SW117-01 |
| | | | 56 | Spool Tension Kit Include 56A - Spool Tension Knob Assembly 57 - Spool Tension Washer Kit | CX4033-06 |
| | | | 57 | Spool Tension Washer Kit Include 57A - Spool Tension Washer 57B - Spool Tension Collar 57C - Spool Cushion Washer | QW4032-01 |
| | | | 58 | Crank Shaft Ball Bearing | TW058-01 |
| | | | 59 | Star Drag Washer | ZW032-01 |
| | | | 60 | Drag Click Spring Assembly | YX4114-01 |
| | | | 61 | Spring "D" Washer | JX046-01 |
| | | | 62 | Star Drag Washer | ZW032-01 |
| | | | 63 | Star Drag | UX055-01 |
| | | | 64 | Handle Ratchet Spring | UX040-01 |
| | | | 65 | Handle Ratchet | UX054-01 |
| | | | 66 | Handle Washer | UX032-01 |
| | | | 67 | Handle Assembly | UX318-03 |