


# QUANTUM

## IR410CXA

For parts and service  
 call toll free: 1-888-404-1119  
 www.mikesreelrepair.com



Quantum IRON IR410CXA Part List					
KEY #	IR410CXA	DESCRIPTION	KEY #	IR410CXA	DESCRIPTION
1	FV323-05	Palm Side Cover Assembly	42	JX045-01	Drag "D" Washer
2	XX038-02	Spool Shaft Washer	43	CW052-02	Sleeve - One Way Bearing
3	JX106-01	Bearing - Spool Shaft	44	TW058-01	Bearing - Crank Shaft(U)
4	JX080-01	Clip Ring	45	JX038-01	Crank Shaft Washer
5	FV321-01	Spool Assembly	46	JX066-02	Crank Shaft Guide
6	XX044-01	Brake Shoe B	47	JX073-01	O-Ring - Thumb Screw
7	JX106-01	Bearing - Spool Shaft	48	XX374-03	Thumb Screw Assembly
8	FV301-02	Frame Assembly	49	XX024-14	Right Side Cover
9	QW120-01	E-Clip - Worm Shaft	50	QW123-01	Right Side Cover Screw
10	JX067-01	Bushing - Worm Shaft	51	JX105-01	Spring - Tension Knob
11	JX347-02	Line Guide Carrier Assembly	52	QW032-02	Washer - Spool Tension
12	JX006-02	Line Guide Pawl	53	JX082-01	Washer - Cushion
13	JX035-01	Washer - Line Guide Pawl	54	XX033-01	Spool Tension Knob
14	JX007-02	Screw - Line Guide Carrier	55	JX046-01	Spring "D" Washer
15	NX092-01	E-Clip - Kick Lever Guide Post	56	XX355-02	Star Drag Assembly
16	XX035-01	Washer - Kick Lever Guide	57	NX054-01	Handle Washer
17	JX050-01	Screw - Thumb Rest	58	JV318-01	Handle Assembly
18	FV009-01	Thumb Rest	59	QW003-01	Handle Nut
19	FV061-01	Line Guide Carrier Guide	60	JX034-02	Handle Nut Cap
20	FV016-01	Worm Shaft Guide	61	QW123-01	Handle Nut Cap Screw
21	FV372-01	Worm Shaft Assembly	62	JX363-01	Anti Reverse Pawl Assembly
22	JX025-01	Pinion Yoke	63	JX098-01	Post - Anti Reverse pawl
23	JX040-01	Yoke Spring	64	XX125-01	Screw - Clicker Pawl
24	XX011-01	Pinion Gear	65	JX110-01	Clicker Spring
25	JX017-01	Bushing - Crank Shaft(L)	66	JX114-01	Clicker Pawl
26	QW120-01	E-Clip - Crank Shaft	67	JX084-01	Clicker Cam
27	JX002-01	Retainer - Crank Shaft	68	JX125-01	Screw - Clicker Spring Holder
28	JX107-01	Screw - Crank Shaft Retainer	69	JX103-01	Clicker Spring Holder
29	JX077-01	Kick Lever	70	JX022-01	Spring - Clicker Cam
30	JX097-01	Spring - Kick Lever	71	JX041-01	Click Cam Actuator
31	JX068-01	Bushing - Release Slider Guide	72	JX075-01	C-Clip
32	JX104-01	Spring - Release Slider	73	JX109-02	Click Lever
33	XX050-01	Screw - Release Slider	74	QW053-05	Screw - Click Lever
34	JX339-02	Release Slider Assembly	75	ZW063-01	One Way Bearing
35	JX102-01	Post - Kick Lever Guide	76	JX121-01	Washer - Thumb Screw
36	JX008-01	Crank Shaft	77	FV098-01	Idel Gear Post
37	FV112-01	O/S Drive Gear	78	FV127-01	O/S Idel Gear
38	JX083-01	Trip Ratchet	79	FV351-01	Spool Cover Assembly
39	QW111-01	Washer - Ratchet	80	AV125-01	Spool Cover Screw
40	XX012-01	Drive Gear	81	JX117-01	Tension Knob Bushing
41	JX059-01B	Drag Disc			