



Quantum ICON IC300C Bait Cast Reel Part List							
Key #	Description	Part No.		Key #	Description	Part No.	
		IC300C				IC300C	
1	Palm Side Cover Assembly	EX323-02		38	Release Slider	EX039-01	
2	Magnet Dial	EX026-01		39	Thumb Bar Screw	ZW053-01	
3	Magnet Dial Friction Ring	NX105-01		40	Release Slider Guide Washer	EX121-01	
4	Slide Cam	EX028-01		41	Release Slider Screw	QW125-02	
5	Slide Cam Spring	EX071-01		42	Release Slider Spring	EX104-01	
6	Spool Cover	EX051-01		43	Crank Shaft Bushing	ZW017-02	
7	Spool Cover Screw	QW125-02		43	Crank Shaft Bearing	N/A	
8	Spool Shaft Washer	QW032-04		44	E-Clip	QW120-01	
9	Spool Shaft Bushing (Palm)	N/A		45	Crank Shaft Retainer	EX002-01	
9	Spool Shaft Bearing (Palm)	QV017-01		46	Crank Shaft Retainer Screw	EX076-01	
10	Clip Ring	HV080-01		47	Crank Shaft	EX008-01	
11	Magnet Assembly	EX330-01		48	O/S Drive Gear	EX112-01	
12	Magnet Plate Screw	QW076-01		49	Trip Ratchet	EX083-01	
13	Spool Assembly	EX321-01		50	Trip Ratchet Washer	QW111-01	
14	Clip Ring	EX080-01		51	Drive Gear	FX012-01	
15	Spool Shaft Bearing (Gear)	EX017-01		52	Drag Disc	JX059-01	
16	Frame Assembly	EX301-01		53	Drag "D" Washer	EX045-01	
17	E-Clip	NX092-01		54	One Way Bearing Sleeve	EX052-01	
18	Worm Shaft Bushing (Palm)	EX067-01		55	One Way Bearing	EX063-01	
19	Worm Shaft	EX072-01		56	Gear Side Cover	EX024-02	
20	Stablizer Bar	CX061-02		57	Gear Side Cover Screw	JX050-02	
21	Side Cover Locking Lever	EX119-01		58	Spool Tension Knob O-Ring	QW101-01	
22	Side Cover Locking Spring	ZW096-01		59	Spool Tension Knob Bushing	EX117-01	
23	Front Support	EX099-02		60	Spool Tension Washer	QW032-04	
24	Line Guide Carrier	EX047-01		61	Spool Tension Knob Washer	EX038-01	
25	Line Guide Pawl	ZW006-01		62	Spool Cushion Washer	EX082-01	
26	Line Guide Carrier Washer	BV035-01		63	Spool Tension Knob	EX033-01	
27	Line Guide Carrier Screw	ZW007-01		64	Spring "D" Washer	JX046-01	
28	Worm Shaft Guide	EX016-01		65	Star Drag Washer	EX032-01	
29	Worm Shaft Washer	EX035-01		66	Star Drag	EX055-01	
30	O/S Pinion Gear	EX085-01		67	Handle Washer	NX054-01	
31	E-Clip	NX090-01		68	Handle Assembly	EX318-01	
32	Thumb Bar	EX009-01		69	Handle Nut	QW003-01	
33	Pinion Yoke	EX025-01		70	Handle Nut Cap	JX034-01	
34	Pinion Yoke Spring	QW040-01		71	Handle Nut Cap Screw	QW123-01	
35	Pinion Gear Assembly	FX311-01		72	Hood	EX027-02	
36	Kick Lever Spring	EX097-01		73	Hood Screw	EX107-01	
37	Kick Lever	EX077-01					