

QUANTUM®

IR300HPT

Quantum IR300HPT Baitcast Reel Part List

| Key # | Description | Part No. | Qty. | Key # | Description | Part No. | Qty. |
|-------|-------------------------------|-----------|------|-------|--|-----------|------|
| 1 | Palm Side Cover Kit | JA4023-01 | 1 | 36 | Spool Tension Knob Bearing Retainer | EB080-01 | 1 |
| 1A | Palm Side Cover | JA023-01 | 1 | 37 | Spool Tension Knob Ball Bearing | SW017-01 | 1 |
| 1B | Spool Cover Assembly | JA351-01 | 1 | 38 | Gear Side Cover Assembly | JA324-01 | 1 |
| 1C | Spool Cover Screw | JA076-01 | 3 | 39 | Nylon Washer | LA031-01 | 2 |
| 2 | Spool Shaft Washer(Palm Side) | QW032-04 | 1 | 40 | Thumb Screw | JA050-01 | 1 |
| 3 | Spool Assembly | JA351-01 | 1 | 41 | Spool Tension Knob Click Spring | PA114-01 | 1 |
| 4 | Frame Assembly | JA301-01 | 1 | 42 | Spool Tension Knob Kit | PA4033-06 | 1 |
| 5 | Thumb Bar | JA009-01 | 1 | 42A | Spool Tension Knob | PA033-04 | 1 |
| 6 | Thumb Bar Screw | EB107-01 | 2 | 42B | Spool Cushion Washer | EX082-01 | 1 |
| 7 | Kick Lever Spring | JA097-01 | 1 | 42C | Spool Tension Knob Washer "B" | PW032-01 | 1 |
| 8 | Kick Lever | JA077-01 | 1 | 42D | Spool Tension Knob Washer "A" | QW032-04 | 1 |
| 9 | Release Slider Spring | JA104-01 | 1 | 42E | Click Ratchet | PW113-01 | 1 |
| 10 | Release Slider | JA039-01 | 1 | 42F | C-Ring | PW080-01 | 1 |
| 11 | Release Slider Plate | JA161-01 | 1 | 43 | Crank Shaft E-Clip | PA090-01 | 1 |
| 12 | Release Slider Screw | EB125-01 | 2 | 44 | Crank Shaft Ball Bearing | SW017-01 | 1 |
| 13 | Pinion Yoke | FB028-01 | 1 | 45 | Crank Shaft Retainer Plate | JA094-01 | 1 |
| 14 | Pinion Yoke Spring | KW040-01 | 2 | 46 | Crank Shaft Retainer Plate Screw | JA136-01 | 1 |
| 15 | Gear Side Cover Screw "A" | JA123-01 | 2 | 47 | Worm Shaft Drive Gear | JA112-01 | 1 |
| 16 | Gear Side Cover Screw "B" | JA107-01 | 2 | 48 | Crank Shaft | JA008-01 | 1 |
| 17 | Pillar | JA061-01 | 1 | 49 | Trip Ratchet | JA083-01 | 1 |
| 18 | Stopper Assembly | JA063-01 | 1 | 50 | Trip Ratchet Washer | JA111-01 | 1 |
| 19 | Plate | JA030-01 | 1 | 51 | Drag Washer | KA045-01 | 1 |
| 20 | Plate Screw | JA107-01 | 1 | 52 | Drag Key Washer "A" | JA059-01 | 3 |
| 21 | Gear Kit | JA4011-01 | 1 | 53 | Drag Key Washer "B" | JA048-01 | 1 |
| 21A | Pinion Gear | JA011-01 | 1 | 54 | Drag Key Washer "C" | JA045-01 | 1 |
| 21B | Drive Gear | JA012-01 | 1 | 55 | One Way Clutch Sleeve | JA052-01 | 1 |
| 22 | Front Support | JA099-01 | 1 | 56 | Crank Shaft Ball Bearing (Handle Side) | TW058-02 | 1 |
| 23 | Front Support Screw | KW107-01 | 4 | 57 | Collar | JA081-01 | 1 |
| 24 | Worm Shaft E-Clip | NX090-01 | 1 | 58 | Bearing Washer | KW032-01 | 1 |
| 25 | Worm Shaft Pinion Gear | JA085-01 | 1 | 59 | Rubber | JA155-01 | 1 |
| 26 | Worm Shaft Washer(Gear Side) | PA035-01 | 1 | 60 | Star Drag Clicker Spring Assembly | PA4114-01 | 1 |
| 27 | Worm Shaft Bushing | RA067-01 | 1 | 61 | Star Drag Spring Washer | JX046-01 | 2 |
| 28 | Worm Shaft Kit | JA4072-01 | 1 | 62 | Star Drag Washer | JA032-01 | 2 |
| 28A | Line Guide Pawl Washer | BV035-01 | 1 | 63 | Star Drag | PA055-05 | 1 |
| 28B | Line Guide Pawl | KW006-01 | 1 | 64 | Handle Washer | JA054-01 | 1 |
| 28C | Worm Shaft | JA072-01 | 1 | 65 | Handle Assembly | JA318-01 | 1 |
| 29 | Line Guide Pawl Screw | KW007-01 | 1 | 66 | Handle Nut | JA003-01 | 1 |
| 30 | Line Guide Carrier Assembly | JA347-01 | 1 | 67 | Handle Nut Retainer | KW034-04 | 1 |
| 31 | Worm Shaft Ball Bearing | PA017-01 | 1 | 68 | Handle Nut Retainer Screw | QW123-02 | 1 |
| 32 | Worm Shaft Guide | JA016-01 | 1 | 69 | Release Slider Link | JA036-01 | 1 |
| 33 | Worm Shaft Bearing | JA017-01 | 1 | 70 | Release Slider Link Screw | EB125-01 | 1 |
| 34 | Worm Shaft Washer(Palm Side) | EB032-01 | 1 | 71 | Spring | JA096-01 | 1 |
| 35 | Worm Shaft E-Clip | JA090-01 | 1 | | | | |