


QUANTUM

Tour Edition

TE30PTIAS



TOUR EDITON SPINNING REEL Part List

Key #	Description	Part No.		Key #	Description	Part No.	
		TE30				TE30	
1	Drag Knob Assembly	CG332-01		32	Clutch Retaining Ring	TK060-01	
2	Retainer Ring	RQ038-01		33	Clutch Seal Plate	TK166-01	
3	Drag Washer "D"	SQ080-01		34	Clutch Unit	CG463-01	
4	Drag Washer "B"	RQ033-01		35	Pinion Bearing Screw "A"	TK057-01	
5	Drag Washer "A"	RQ081-01		36	Pinion Bearing Screw "B"	TK057-11	
6	Drag Washer "C"	RQ080-01		37	Pinion Ball Bearing	UK028-01	
7	Spool Assembly	TK321-11		38	Pinion	SQ011-01	
8	Spool Ball Bearing	EH158-01		39	Stopper Cam Spring	TK089-01	
9	Bearing Retainer Ring	BG080-01		40	Stopper Cam	TK090-01	
10	Spool Adjust Washer	PT030-01		41	Stopper Lever	RQ059-01	
11	Click Gear	RQ037-01		42	Pinion Bushing	SQ141-03	
12	Rotor Nut Lock Screw	RK094-01		43	Handle Screw Assembly	BG354-02	
13	Rotor Nut Cover	TK214-01		44	Body Assembly	TK301-11	
14	Main Shaft Bushing	TK213-01		45	Body Rear Cover "Bottom"	TK140-55	
15	Rotor Nut	TK006-01		46	Body Rear Cover "Top"	TK140-03	
16	Line Roller Screw	AQ108-01		47	Side Cover Screw Washer	RQ142-01	
17	Line Roller Collar	BG104-01		48	Side Cover Screw "D"	RQ057-11	
18	Line Roller Washer	DH102-01		49	O/S Gear Ball Bearing	EH158-01	
19	Line Roller	CH004-01		50	O/S Gear	TQ053-51	
20	Line Roller Balling Bearing	GH202-01		51	O/S Slider	TK025-01	
21	Bail Assembly	N/A		52	Main Shaft Screw	RQ100-01	
22	Arm Lever Assembly	CG307-01		53	Trip Ramp	TK119-01	
23	A/L Cover Screw	GU077-01		54	Body Ball Bearing	BL157-01	
24	Armler Cover	TK087-04		55	Drive Gear Assembly	AT312-51	
25	Kick Lever	TK019-01		56	Side Cover Ball Bearing	BL157-01	
26	Bail Pivot Insert	N/A		57	Side Cover Assembly	TK323-11	
27	Bail Pivot Bushing	TK110-01		58	Side Cover Screw "C"	SK057-11	
28	Bail Pivot Ball Bearing	GH202-01		59	Side Cover Screw "B"	SK057-01	
29	Bail Pivot Screw	TK111-01		60	Side Cover Screw "A"	RQ057-04	
30	Rotor Assembly	TK309-11		61	Handle Assembly	CG318-01	
31	Main Shaft	TQ015-02					