


# QUANTUM<sup>®</sup>

## TKVD25PTi



### TOUR KVD SPINNING REEL PART LIST

Key #	Description	Part No.	Qty.	Key #	Description	Part No.	Qty.
		TKDV25PTi				TKVD25PTi	
1	Drag Knob Assembly	VAA332-03	1	27	Line Roller Ball Bearing	GH202-01	1
2	Spool Assembly	UAA321-02	1	28	Bail Assembly	UAA347-02	1
2a	Spool Cap Screws	CF107-01	6	29	Rotor Adjust Washer	BAA110-02	1
2b	Spool Cap	UAA144-91	1	30	Clutch Bearing Cap	UAA040-03	1
2c	Spool Lip	UAA143-02	1	31	Clutch Bearing Adapter	UAA190-01	1
2d	Drag Washer "D"	UAA080-01	2	32	Top Pinion Ball bearing	TW058-03	1
2e	Drag Washer "B"	UAA033-01	2	33	Sleeve	UAA139-01	1
2f	Drag Washer "A"	UAA081-01	1	34	One Way Clutch	UAA063-01	1
2g	Spool	UAA021-02	1	35	Bottom Pinion Ball Bearing	TW058-03	1
2h	Drag Washer "C"	UAA033-02	1	36	Pinion Bushing	BAA213-02	1
2j	Spool Click	AAA103-02	1	37	O-Ring	VAA101-01	1
2k	Spool Click Spring	BAA068-02	1	38	Trip Ramp Screw	UAA123-04	1
2l	Spool Click Screw	CAA077-01	1	39	Trip Ramp	UAA119-01	1
3	Retainer Ring	UAA038-01	1	40	Dust Cap	UAA054-03	1
4	Spool Ball bearing	CH027-01	1	41	Body Assembly	UAA301-07	1
5	Spool Ball Bearing Washer	UAA076-01	1	42	O/S Guide Pin "A"	UAA093-02	1
6	Spool Adjust Washer	UAA030-01	1	43	O/S Guide Pin "B"	UAA098-02	1
7	Clicker Gear	UAA037-01	1	44	Body Rear Cap	UAA140-03	1
8	Adapter Pin	UAA134-01	1	45	Rear Cap Screw "A" - M2 x 5mm	UAA123-06	1
9	Shaft Drag Adapter	UAA117-01	1	46	Rear Cap Screw "B" - M2 x 5mm	UAA123-06	1
10	Rotor Nut Lock Screw	UAA094-02	1	47	Body Drive Gear Bearing	TW058-03	1
11	Rotor Nut	BAA006-02	1	48	Drive Gear Kit	BAA412-04	1
12	Main Shaft	UAA015-01	1	48a	48a - Drive Gear	BAA012-03	1
13	Rotor Arm Sleeve	UAA042-02	2	48b	48b - Pinion Gear	UAA011-02	1
14	Ball Bearing	BAA158-01	1	49	Drive Gear Adjust Washer	BAA105-04	1
15	E-Clip	QW120-01	2	50	Sidecover Drive Gear Bearing	TW058-03	1
16	Rotor	UAA009-04	1	51	Sidecover Assembly	UAA323-07	1
17	Kick Lever	UAA019-01	1	52	Sidecover Screw "A" - M2.6 x 8mm	UAA057-02	2
18	Bail Actuator	BAA031-01	1	53	O/S Gear Bearing	CT157-02	1
19	Bail Spring	BAA022-01	1	54	O/S Gear Assembly	UAA353-01	1
20	Arm Lever Cover	UAA087-03	1	55	O/S Slider	UAA025-01	1
21	Arm Lever Cover Screw	CW125-02	1	56	Main Shaft Screw	BAA100-01	1
22	Line Roller Screw	BAA108-02	1	57	Sidecover Screw "B" - M2.6 x 6mm	UAA050-01	1
23	Arm Lever	UAA007-02	1	58	Handle Assembly	VAA318-04	1
24	Line Roller Collar	CAA102-01	1	58e	Handle Knob Cap	BB115-02	1
25	Line Roller Washer	BAA102-01	1	59	Spool Bushing	UAA027-01	1
26	Line Roller	BAA004-02	1	60	O-Ring	UAA101-01	1