



KEY NO.	DESCRIPTION	PART NO.		KEY NO.	DESCRIPTION	PART NO.	
		PREMIER 20	PREMIER 30			PREMIER 20	PREMIER 30
1	Space Washer	1195751	1195751	40	Handle Screw Cover	1221484	1221484
2	O-Ring	1195755	1195755	41	Screw (6 Req)	1221488	1221488
3	Bearing Sleeve	1195758	1195758	42	Bearing Retainer (2 Req)	1221490	1221490
4	Ball Bearing	1195757	1195757	43	Screw	1195720	1195720
5	Seal	1195761	1195761	44	Oscillation Mount	1221494	1221494
6	Spool Shaft Washer	1195763	1195763	45	Idle Gear	1195766	1195767
7	Spool Shaft	1221451	1221451	46	Screw	1221496	1221496
8	Screw	1195642	1195642	46A	Washer (2 Req)	1252583	1252583
9	Screw (2 Req)	1221453	1221453	47	Gear Box	1221497	1221497
10	Bail Arm	1221454	1221454	48	Screw (2 Req)	1221499	1221499
11	Ball Bearing (4 Req)	1195641	1195641	49	Switch Spring	1221500	1221500
12	Line Roller	1195620	1195620	50	Switch Lever	1221501	1221501
13	Spacer	1195778	1195778	51	IAR Switch	1221502	1221502
14	O-Ring	1195591	1195591	52	Clip	1221504	1221504
15	Clip	1195592	1195592	53	Stem	1221422	1221423
16	Bail Holder	1221456	1221456	54	Guide Bar	1221428	1221428
17	Bail Wire	1221458	1221459	55	Main Gear	1221509	1221510
18	Screw	1221460	1221460	56	Shim	1195560	1195560
19	Rotor Locking Plate	1195770	1195770	57	Handle Assembly	1221514	1221515
20	Rotor Nut	1195643	1195643	58	Oscillation Gear	1195801	1195801
21	Screw (2 Req)	1221462	1221462	59	Screw	1195659	1195659
22	Bail Arm Cover	1221463	1221463	60	Screw	1195812	1195812
23	Pivot Lever	1195617	1195617	61	Oscillation Slider	1195651	1195651
24	Bail Spring Bushing	1195619	1195619	62	Drag Knob	1221522	1221522
25	Bail Spring	1195613	1195613	63	Screw (4 Req)	1221524	1221524
26	Bail Trip Bar	1221465	1221466	64	Spool Top	1221525	1221526
27	Bushing (2 Req)	1221467	1221467	66	Spool	1221532	1221533
28	Rotor	1221468	1221469	67	Line Clip Spring	1195693	1195693
29	Bail Holder Cover	1221472	1221472	68	Line Clip	1221543	1221543
30	Rotor Brake Linkage	1221474	1221474	69	Keyed Washer (2 Req)	1221544	1221545
31	Rotor Brake Spring	1221475	1221475	70	Drag Washer (2 Req)	1195729	1221548
32	Rotor Brake Pad	1221476	1221476	71	Spool Washer	1221549	1221550
33	Screw (3 Req)	1221477	1221477	72	O-Ring	1195716	1221553
34	Bearing Holder Cover	1221478	1221479	73	Spool Click Retainer	1221554	1221554
35	Ball Bearing (4 Req)	1181780	1181780	74	Spool Click	1221555	1221555
36	Bearing Holder	1195573	1195573	75	Spool Bottom	1221556	1221557
37	Clutch Spring	1221480	1221480	76	Spool Assembly	1221558	1221559
38	Clutch Assembly	1195773	1195773	77	Alum. Spare Spool Assy. (Not Shown)	1221569	1221570
39	Pinion	1195566	1195567				