



S-5/6 PARTS LIST

KEY NO	PARTS NO	PARTS NAME
100	31000097	BODY ASSY.
102	31020008	BODY FOOT
111	31110004	CLICK PAWL
300	33000019	DRAG KNOB
303	33030006	FIXED PLATE
304	33040014	CLICK PAWL
305	33050018	CLICK PAWL SPRING
314	33140001	SPRING WASHER
315	33150002	DISK BREAK ASSY.
332	33320006	BREAK BLOCK
332-1	33320007	BREAK BLOCK
333	33330002	COMPRESSION SPRING
335	33350001	DRAG CLUTCH PLATE
336	33360002	DRAG KNOB NUT
400	34000153	SPOOL ASSY.
400-1	34000154	SPOOL
403	34030005	CLICK PAWL
404	34040006	HANDLE KNOB
405	34050008	HANDLE KNOB SCREW
408	34080014	SPOOL RETAINER
409	34090001	SPOOL RETAINER SPRING
410	34100018	SPOOL COVER ASSY.
413	34130003	COUNTER BALANCE
416	34160003	ONE WAY BEARING BUSHING
420	34200001	HANDLE KNOB BUSHING
509	35090001	"E" RETAINER
901	29010001	FIXED WASHER
910	0910086	BEARING ASSY.
920	0920056	WASHER
920	0920077	WASHER
930	0930077	SCREW
930	0930081	SCREW
930	0930084	SCREW
930	0930117	SCREW
930	09301219	SCREW