



### SLR-50WII PARTS LIST

KEY NO	PARTS NO	PARTS NAME	KEY NO	PARTS NO	PARTS NAME
100	11001522	MAIN BODY	601	16010004	DRAG NUT
101	11010031	BODY LOGO	602	16020036	ADJUST BLOCK
102	11020017	BODY FOOT	605	16050093	LEVER DRAG
103	11030003	BODY FOOT SCREW	605-1	16050108	LEVER DRAG
104	11040001	BODY FOOT NUT	607	16070048	PINION GUARD
107	11070033	LINE GUARD	608	16080008	DRAG WASHER RETAINER
107-1	11070032	LINE GUARD	609	16090020	SPRING WASHER
108	11080016	HANGER	611	16110049	EARED WASHER
114	11140005	CLAMP	612	16120063	KEY WASHER
115	11150006	WUNG SCREW	613	16130007	COMPRESSION SPRING
116	11160005	WING NUT	700	17000305	DRIVE GEAR
117	11170002	RETAINER NUT	700-1	17000307	DRIVE GEAR
200	12001825	MAIN SIDE PLATE	701	17010260	DRIVE GEAR SHAFT
201	12010027	ANTI-RE PAWL	702	17020345	PINION GEAR
203	12030003	CONTROL PIN	702-1	17020347	PINION GEAR
204	12040007	COMPRESSION SPRING	717	17170004	MAIN SHAFT PIN
204-1	12040002	COMPRESSION SPRING	718	17180189	MAIN SHAFT
204-2	12040011	COMPRESSION SPRING	723	17230007	SILENT SPRING
204-3	12040029	COMPRESSION SPRING	900	19000004	E RETAINER
205	12050034	DECORATION PLATE	900	29000001	E RETAINER
206	12060006	LEVER DRAG STOPPER CAP	913	19130002	SPRING WASHER
207	12070074	HOLDED PLATE	910	0910433	BALL BEARING
208	12080083	SIDE PLATE COVER	910	0910099	BALL BEARING
215	12150025	HOLD PLATE BUSHING	910	0910385	BALL BEARING
215-1	12150027	HOLD PLATE BUSHING	910	0910407	BALL BEARING
215-2	12150018	HOLD PLATE BUSHING	920	0920154	WASHER
215-3	12150021	HOLD PLATE BUSHING	920	0920490	WASHER
217	12170013	ANTI-RE PAWL SPRING	920	0920005	WASHER
217-1	12170017	ANTI-RE PAWL SPRING	920	09201000	WASHER
225	12250002	BUSHING	920	0920319	WASHER
226	12260003	BALL	920	0920412	WASHER
300	13000961	VICE SIDE PLATE	920	0920426	WASHER
303	13030068	CLICK KNOB	920	0920481	WASHER
304	13040019	CLICK PAWL	920	0920207	WASHER
305	13050014	CLICK PAWL SPRING	920	0920282	WASHER
311	13110080	SIDE PLATE COVERS	920	0920263	WASHER
400	14000851	SPOOL	930	0930402	SCREW
401	14010036	CLICK GEAR	930	0930196	SCREW
402	14020008	LINE HOLDER	930	0930211	SCREW
404	14040013	PRESSURE LOAD BLOCK	930	09301132	SCREW
405	14050028	SPOOL COVER	930	0930469	SCREW
500	15000348	HANDLE ASSY.	930	0930646	SCREW
501	15010010	HANDLE NUT	930	0930893	SCREW
507	15070035	PUSH BUTTON	930	09301129	SCREW
507-1	15070034	PUSH BUTTON	930	09301130	SCREW
507-2	15070027	DRIVE GEAR TRANSMISSION PIN	930	09301115	SCREW
508	15080002	PUSH BUTTON SPRING	930	09301113	SCREW
513	15130026	HANDLE COVER	930	09301088	SCREW
515	15150002	HANDLE SCREW	930	09301023	SCREW
516	15160029	HANDLE NUT RETAINER	930	0930003	SCREW
517	15170004	TRANSMISSION PIN	930	0930452	SCREW
600	16000101	CAST CONTROL CAP	940	0940031	O RING