



SRT-1002 PARTS LIST

KEY NO	PARTS NO	PARTS NAME	KEY NO	PARTS NO	PARTS NAME
100	31000737	MAIN BODY	420-1	34200003	HAND KNOB PAD
101	31010038	MAIN SHAFT	420-2	34200004	HAND KNOB PAD
102	31020056	BODY FOOT	500	35000016	HANDLE ARM
104	31040038	SHAFT CREW ASSY.	502	35020003	CLICK PLATE NUT
108	31080006	CLICK KNOB ASSY.	615	16150180	STRA DRAG
109	31090026	CLICK BUTTON	900	19000002	E RETAINER
303	33030007	FIXED PLATE	910	0910035	BALL BEARING
305	33050017	CLICK PAWL SPRING	920	0920140	WASHER
310	33100031	DRAG WASHER	920	0920472	WASHER
311	33110004	EARED WASHER	920	0920058	WASHER
315	33150013	DISK BRAKE	920	0920094	WASHER
316	33160007	PACKING WASHER	930	0930096	SCREW
324	33240005	ANTI-RE LEVER	930	0930100	SCREW
327	33270004	PACKING PIN	930	0930476	SCREW
400	34000728	SPOOL	930	0930200	SCREW
402	34020034	SPOOL BUSHING	930	0930078	SCREW
404	34040026	HANDLE KNOB	930	0930896	SCREW
405	34050013	HANDLE KNOB RIVET	940	0940047	O RING
410	34100056	SPOOL COVER	940	0940011	O RING

12.17.2009

309OKA03601121