




# Baitcast LP Reel Parts List

Use this parts list for ordering replacement parts for your Pflueger Baitcast Reel. When ordering, please specify which reel you own and the model number printed on the reel body.

For Parts and Service  
call toll free 1-888-404-1119  
www.mikesreelrepair.com

*Blue Color*



For Parts and Service  
call toll free 1-888-404-1119  
www.mikesreelrepair.com

Part #	Part Name	Part #	Part Name	Part #	Part Name
1	FRAME	30	IDLER(L) WASHER (A)	60	STAR DRAG ASSEMBLY
2	CLUTCH BAR	31	BEARING PLATE	61	LEAF SPRING
3	CLUTCH LINK	32	IDLER(L) WASHER (B)	62	HANDLE ASSEMBLY (INCL 4BB)
4	CLUTCH BAR SCREW	33	E-RING	64	HANDLE NUT CAP
5	LINE GUIDE ASSEMBLY	34	BEARING PLATE SCREW	65	HANDLE NUT CAP SCREW
6	WORM SHAFT	35	PINION YOKE	66	SPOOL ASSEMBLY (INCL 1BB)
7	LINE GUIDE PIPE	36	PINION GEAR	67	BRAKE SHOE HOLDER
8	BALL BEARING	37	PINION YOKE SPRING (X2)	68	BRAKE SHOE (X6)
9	WORM SHAFT BUSHING (A)	38	RATCHET	69	BRAKE SHOE SPRING (X6)
10	IDLER(S)	39	RATCHET WASHER	70	BRAKE HOLDER PLATE
11	WORM SHAFT PIN	40	DRIVE GEAR	71	BRAKE HOLDER PLATE SCREW(X3)
12	WORM SHAFT BUSHING (B)	41	DRAG WASHER (B)	72	LEFT SIDE COVER
13	WORM SHAFT WASHER	42	DRAG WASHER (D)	73	LOCKING PIN
14	E-RING	43	SLEEVE WASHER (OPTIONAL)	74	LOCK PIN SPRING
15	PILLAR	44	SLEEVE	75	PUSH BUTTON ASSEMBLY
16	LINE GUIDE PAWL	45	RIGHT SIDE COVER	76	SPOOL COVER ASSEMBLY
17	SPACER (OPTIONAL)	46	SPACER	77	SPOOL COVER SCREW (*3)
18	PAWL CAP	47	ONE WAY CLUTCH	78	SPOOL SPACER (A)
19	FRONT COVER	48	O-RING	79	BALL BEARING
20	FRONT COVER SCREW (*2)	49	BALL BEARING	80	BEARING RETAINER
21	RETURN PAWL	50	BEARING RETAINER		
22	CLUTCH SPRING	51	SPOOL SPACER (B)		
23	CLUTCH CAM	52	TENSION WASHER		
24	CAM PLATE	53	CAST CONTROL CAP		
25	CLAM PLATE SCREW (X3)	54	RIGHT SIDE COVER SCREW-(A)		
26	RETURN PAWL SPRING	55	RIGHT SIDE COVER SCREW-(B)		
27	BALL BEARING	56	RIGHT SIDE COVER SCREW-(C)		
28	CRANK SHAFT	57	RIGHT SIDE COVER SCREW-(C)		
29	IDLER(L)	58	DRAG SPRING WASHER (X2)		
		59	SPACER		