


SKP 3000A

Shakespeare Baitcast Reel Parts List

Use this parts list for ordering replacement parts for your Shakespeare Baitcast Reel. When ordering, please specify which reel you own and the model number printed on the reel body.



Part #	Part Name	Part #	Part Name
1	Left Side Plate Screw - 1146181	28	Yoke Spring
2	Left Side Plate	29	Yoke
3	Level Wind Gear Frame	30	Pinion Gear - 1145974
4	Bait Clicker Button	31	Crankshaft
5	Bait Clicker Spring	32	Drag Friction Disc - 1146848
6	Thumb Rest Hood	33	Main Gear
7	Level Wind Gear - 1145591	34	Drag Pressure Plate
8	E-Ring - 1145278	35	One-Way Clutch Bearing
9	Main Body Assembly	36	Drag Spring Washer
10	Level Wind Pinion Gear - 1145592	37	Clutch Bearing Inner Race
11	Spool Assembly	38	Label
12	Centrifugal Brake Shoe	39	Right Side Plate
13	Worm Shaft - 1146298	40	Multi-Purpose Screw
14	Line Guard	41	Star Drag Handle
15	Line Guide - 1145728	42	Handle Spring Washer
16	Line Guide Pawl - 1145919	43	Crank Handle Assembly
17	Washer	44	Handle Nut
18	Line Guide Pawl Cap	45	Shim Washer
19	Bushing	46	E-Ring - 1145278
20	Washer	47	Retaining Cap
21	Retaining Ring	48	Ball Bearing
22	Gear Plate	49	Retaining Clip
23	Anti-Reverse Pawl	50	O-Ring
24	Thumb Button	51	Cast Control Brass Washer
25	Latch Keeper	52	Cast Control Rubber Washer - 1146846
26	Keeper Screw	53	Cast Control Knob
27	Latch Spring		