

PARTS NLA

For Parts and Service
Call 1-888-404-1119
www.mikesreelrepair.com


SKP 4000

Shakespeare®

SKP 4000

FTD--2001

Older



1	Main Body Assembly	61	Latch Spring
2	Left Side Plate	63	Multi-Purpose Screw (3)
3	Left Side Plate Screw (3)	64	Level-Wind Retainer
4	Decal Seat	65	E-Ring
5	Decal Seat Screw (2)	66	Centrifugal Brake Shoe
7	Level Wind Gear Frame	67	Cast Control Knob
8	Bait Clicker Spring	68	Cast Control Pressure Ring
9	Bait Clicker Button	69	Cast Cntrl Brass Washer
12	Level Wind Gear	69-1	Cast Cntrl Rubber Washer
13	Spool Assembly	70	Cast Control Spring
15	Level Wind Pinion Gear	73	Decal
17	Pinion Gear	78	Bushing
22	Worm Shaft	82	Line Guide Pawl
24	Line Guard	84	Line Guide Pawl Cap
25	Line Guard	85	Washer
28	Right Side Plate Seat Assembly	86	Keeper Screw
29	Right Side Plate	87	Shim Washer
35	Crankshaft	88	Thumb Rest Hood
37	Main Gear	92	Yoke Spring (3)
38	Drag Friction Gear	93	Brass Bushing
40	Drag Pressure Plate A	94	Ball Bearing
41	Drag Washer A	108	Retaining Spring
43	Drag Spring Washer (2)	109	Pawl Retaining Spring
44	Star Drag Handle	36*	Trip Ratchet
46	Handle Spring Washer	39*	Washer
47	Handle Assembly	42*	Drag Washer B
48	Handle Nut	52*	Drag Pressure Plate B
49	E-Ring		
50	Retainer Cap		
51	Latch Keeper		
54	Anti-Reverse Pawl		
57	Thumb Latch	*	REVISION 10/20/00
58	Yoke		

76

Model #	Line Cap	Gear Ratio	Class
SKP 3000	200yds/12# line	5.3:1	Medium Freshwater
SLP 4000	165yds/20# line	5.3:1	Heavy FW/Light SW

10/23/00