


Tidewater TW30LCL

# TIDEWATER®

Use this parts list for ordering replacement parts for your Tidewater reel. When ordering parts, please specify you are ordering for the 10LCL or the 30LCL.



Tension Knob Assy - 1146921

Part #	Part Name	Part #	Part Name
1	Handle Nut Retainer Screw - 1146146	37	Support Plate
2	Handle Nut Retainer	38	Bushing
3	Handle Nut	39	E. Clip
4	Handle Assembly - 1145394	40	Support Plate Screw (X3)
5	Friction Washer - 1146858	41	Bushing
6	Star Drag - 1146918	42	Washer
7	Washer (X2)	43	Screw (10mm) - 1146157
8	Bushing Or Ball Bearing - 1145083	44	Bushing
9	Bushing	45	Riveter (X3)
10	Spring Washer	46	Frame Right Side Cover
11	Spool Tension Knob - 1145218	47	Foot Screw (x2)
12	Spacer, Rubber (X2) - 1146847	48	Spool
13	Spacer - 1146336	49	Frame Support Shaft
14	Spring (X3) - 1146711	50	Line Garnage Support
15	Right Side Plate	51	Level Wind Guard - 1145719
16	Clutch Lever Screw - 1146139	52	Line Garnage Assembly - 1145146
17	Clutch Lever - 1145769	53	Pilot Guide - 1145916
18	Clutch Cam Spring - 1146741	54	Washer - 1146818
19	Clutch Cam	55	Pilot Guide Cap
20	Clutch Plate	56	Foot
21	Clutch Plate Screw - 1146141	57	Worm Shaft - 1146296
22	Anti-Reverse Pawl	58	Lock Plate - 1146020
23	Anti-Reverse Spring	59	Idle Gear - 1145383
24	Anti-Reverse Pawl Pin	60	Left Side Plate
25	Bushing Or Ball Bearing	61	Left Side Cover Assembly
26	Pinion Gear - 1145971	62	Spacer
27	Yoke	63	E. Clip (X2) - 1145278
28	Screw (16.5mm) (X5)	64	Click Pawl - 1145978
29	Screw (10mm) (X2)	65	Plastic Washer
30	Key Washer (X3)	66	Click Button
31	Drag Washer (X4)	67	Click Power Spring - 1146723
32	Main Gear	68	Click Power Spring Screw
33	Eared Washer (X2)	72	Medium Gear Assembly - 1145620
34	Fiber Washer	75	Screw (12.5mm) (X2)
35	Ratchet Gear	76	Screw (14.5mm) (X2)
36	Drive Shaft	77	Screw (14.5mm) (Small Head)

31A-washer - 1146855

12A washer - 1146846