




CALCUTTA TE 51GT 01



Part No.	Description
BNT0001	Handle Nut Plate Screw
BNT0011	Drive Shaft Retainer Screw
BNT0015	Drag Spring Washer
BNT0032	Bearing Retainer (B)
BNT0060	Spacer
BNT0133	Worm Shaft Retainer
BNT0188	"O" Ring
BNT0194	Ball Bearing
BNT0586	Bolt Retainer
BNT0664	Spacer (B)
BNT0686	"E" Lock
BNT0687	Spacer
BNT0799	Friction Washer
BNT1211	Key Washer
BNT1218	Idle Gear (A) Spacer
BNT1636	Clutch Cam Screw
BNT1672	"E" Lock
BNT1696	Cast Control Spacer (B)
BNT1727	Handle Nut Plate
BNT1816	Bearing Retainer (A)
BNT1838	Worm Shaft Washer (B)
BNT1843	Brake Collar (blue)
BNT2127	Star Drag Spacer
BNT2128	Bearing Washer
BNT2143	Ball Bearing
BNT2150	Line Guide Pawl
BNT2170	Ball Bearing
BNT2177	Right Side Plate Spring

Part No.	Description
BNT2213	Clutch Cam Retainer
BNT2224	Spool Tension Spacer (A)
BNT2228	Damper Guide Screw
BNT2360	Drag Washer (C)
BNT2396	Roller Clutch Bearing
BNT2404	Anti-Reverse Pawl
BNT2420	Star Drag Bearing
BNT2421	Roller Clutch Inner Tube
BNT2424	Left Side Plate Screw (long)
BNT2425	Side Plate Open Nut
BNT2426	Open Nut Washer
BNT2427	"O" Ring
BNT2445	Yoke Spring
BNT2458	Anti-Reverse Pawl Pin
BNT2461	Damper (A)
BNT2547	Handle Nut
BNT2549	Star Drag
BNT2552	Drive Shaft
BNT2556	Yoke
BNT2564	Worm Bushing (B)
BNT2666	Idle Gear (A)
BNT2669	Idle Gear (C)
BNT2674	Pawl Stop
BNT2809	Cast Control Cap
BNT2810	Ball Bearing
BNT2811	Left Side Plate Screw (short)
BNT2814	Drag Washer (A)
BNT2815	Anti-Reverse Ratchet

Part No.	Description
BNT2816	Drive Shaft Retainer
BNT2817	Level Wind Guide
BNT2819	Worm Spacer
BNT2820	Worm Shaft
BNT2821	Level Wind Guard
BNT2826	Clutch Plate
BNT2827	Set Pin
BNT2828	Clutch Bar Guide (A)
BNT2829	Clutch Bar Support
BNT2832	Line Guide
BNT2833	Pawl Cap
BNT2835	Damper Guide
BNT2836	Spool Assembly
BNT2837	Brake Case
BNT2856	Handle Assembly
BNT2857	Left Side Plate
BNT2858	Drive Plate
BNT2859	Worm Bushing (A)
BNT2860	Pinion Gear (A)
BNT2861	Clutch Cam
BNT2862	Clutch Pawl
BNT2864	Clutch Bar Guide (B)
BNT2865	Quick-Fire II Clutch Bar
BNT2866	One-Piece Frame
BNT2867	Right Side Plate
BNT2870	Clutch Pawl Spring
BNT1850	Brake Collar (Yellow)