


SHIMAN

1997 Repair Supplement



SOLSTACE 4000RB 97

SO4000RB

Part #	Description	Part #	Description	Part #	Description
RD 0026	Ball Bearing	RD 2934	Flange Screw	RD 3766	Oscillating Slider
RD 0041	Drive Gear Washer	RD 3125	Drag Click Screw	RD 3767	Oscillating Slider Retainer
RD 0050	Anti-Reverse Lever Screw	RD 3359	Line Roller Washer	RD 3768	Drag Knob Spacer
RD 0071	Rotor Nut	RD 3402	Cover Screw	RD 3794	Drag Knob Screw
RD 0111	Drag Coil Spring	RD 3446	Spool Assembly (Graphite)	RD 3869	Anti-Reverse Lockout Spring
RD 0452	Drag Spring Washer	RD 3681	Bail Spring Guide (A)	RD 4161	Trigger Cam
RD 0540	Multi Purpose Screw	RD 3682	Bail Spring	RD 4163	Line Roller Bushing
RD 0642	Side Cover Screw (Small)	RD 3683	Bail Spring Guide (B)	RD 4197	Main Shaft
RD 0779	Bail Hold Support Screw	RD 3685	Bail Trip Lever	RD 4362	Side Cover Screw (LG)
RD 0786	Trigger Screw	RD 3687	Anti-Reverse Ratchet	RD 4367	Line Roller Screw
RD 0787	Nut Lock Screw	RD 3688	Anti-Reverse Lock-out	RD 4373	Quick-Fire II Trigger
RD 0826	Key Washer (A)	RD 3689	Bushing Washer	RD 4374	Bail Assembly
RD 0930	Bail Bearing	RD 3691	Anti-Reverse Pawl	RD 4375	Bail Arm
RD 1008	Handle Lock Washer	RD 3692	Anti-Reverse Pawl Spring	RD 4421	Handle Screw Cap
RD 1511	Lever Spring	RD 3693	Anti-Reverse Cam	RD 4460	Handle Assembly
RD 1520	Anti-Reverse Cam Spring	RD 3694	Drive Gear	RD 4553	Line Roller
RD 2016	Drag Washer H (Cloth)	RD 3695	Oscillating Gear	RD 4906	Anti-Reverse Lever
RD 2108	Eared Washer (B)	RD 3710	Rotor	RD 4911	Spool Assembly Aluminum
RD 2257	Drag Washer (H) Blue	RD 3712	Bail Spring Cover	RD 4917	Side Cover Flange
RD 2346	Drag Washer (C) Cloth	RD 3713	Counterbalance Cover	RD 4924	Side Cover
RD 2432	Drag Shaft	RD 3747	Slider Retainer Screw	RD 4925	Body
RD 2433	Pressure Screw	RD 3763	Pinion Gear	RD 4926	Drag Knob
RD 2541	Anti-Reverse Pawl Screw	RD 3764	Hold Click Spring		
RD 2852	Handle Screw Lock	RD 3765	Drag Click		