



TLD - 15 98

| TLD No. | PARTS NAMES | TLD No. | PARTS NAMES | TLD No. | PARTS NAMES |
|---------|--------------------------|---------|-----------------------|---------|-------------------------|
| 0001 | Handle Lock Screw | 0025 | Dog Spring | 0060 | Pre-Load Spring A |
| 0002 | Handle Lock | 0026 | Dog | 0065 | Side Plate |
| 0003 | Handle Nut | 0027 | Dog Spring Retainer | 0067 | Drag Plate |
| 0005 | Gear Shaft Shield | 0031 | Seal Lock | 0068 | Titanium Drag Washer |
| 0006 | Gear Shaft Thrust Washer | 0036 | Bearing Thrust Washer | 0071 | One-Piece Body |
| 0009 | Pre-Program Dial | 0044 | Pre-Load Spring B | 0072 | Pre-Load Washer A |
| 0010 | Body OOO Seal | 0045 | Pre-Load Body | 0073 | Click Button Washer B |
| 0011 | Lever Shaft Body | 0046 | Cross Pin A | 0172 | OOO Lock |
| 0012 | Drag Control Lever | 0047 | Spacer A | 0181 | Line Guard |
| 0013 | Lever Click Spring | 0048 | Click Gear | 0186 | Cooling Shield |
| 0014 | Click Spring Screw | 0049 | Click Gear Screw | 0191 | Lever Quadrant |
| 0015 | Lever Thrust Ring | 0050 | Cross Pin B | 0197 | Main Gear |
| 0016 | Strike Stop | 0051 | Click Pawl | 0198 | Pinion Gear |
| 0017 | Pressure Spring | 0052 | Click Pawl Washer | 0199 | Pinion Guard |
| 0018 | OOO Lock | 0053 | Click Button Washer A | 0200 | Main Shaft |
| 0019 | Quadrant Anchor Bolt | 0054 | Click Button | 0201 | Spool |
| 0020 | Bolt Shield | 0056 | Click Spring Screw | 0202 | Pressure Release Spring |
| 0021 | Quadrant Screw | 0057 | Click Spring | 0206 | Handle |
| 0022 | Free Spool Detent | 0058 | Spacer B | 0212 | Ball Bearing |
| 0024 | Side Plate Bolt | 0059 | Spacer | 0216 | Ball Bearing |