



**TRITON  
200 G**

TGT No.	PARTS NAMES	TGT No.	PARTS NAMES	TGT No.	PARTS NAMES
0008	Cast Control Cap	0042	Worm Shaft Retainer	0214	Handle Nut
0009	Spacer ÒÀÓ	0043	Worm Shaft Holder Washer	0215	Handle Assembly
0010	Spool Tension Spring	0044	Worm Bearing	0216	Side Plate Screw
0011	Spool Shaft Bushing ÒAÓ	0046	Spacer	0217	Star Drag
0016	Clutch Spring	0047	Line Guide Pawl	0218	Right Side Plate
0020	Drag Spring Washer ÒHÓ	0054	Click Gear	0220	Clutch Lever
0021	Drag Spring Washer ÒGÓ	0055	Idle Gear ÒAÓ	0222	Bearing Spacer (A)
0022	Key Washer ÒFÓ	0056	Idle Gear ÒAÓ Retainer	0224	Bearing Spacer (B)
0023	Drag Washer ÒDÓ	0057	Spool Shaft Bushing ÒBÓ	0225	Drag Washer ÒIÓ
0024	Eared Washer ÒÈÓ	0058	Spacer ÒBÓ	0227	Pawl Cap
0025	Key Washer ÒCÓ	0059	Lock Washer	0228	Line Guide
0026	Eared Washer ÒBÓ	0060	Idle Gear ÒBÓ	0229	Spool Shaft Bushing ÒCÓ
0027	Drive Gear	0061	Idle Gear ÒBÓ Bushing	0230	Spool Shaft Spacer
0028	Drive Shaft Washer	0062	Click Pawl Retainer	0231	Left Side Plate
0029	Anti-Reverse Ratchet	0065	Spacer A	0232	Frame
0030	Drive Shaft	0067	Click Spring	0259	Yoke Plate
0031	Drive Shaft Bushing	0068	Multipurpose Screw	0415	Clutch Lever Screw
0032	Spacer	0072	Level Wind Guard	0416	Clutch Cam
0033	Drive Shaft Retainer	0073	Worm Shaft	0420	Spacer B
0034	Pinion Gear	0074	Stabilizer Bar	0421	Click Pawl
0036	Yoke	0075	Spool	0422	Click Button
0037	Anti-Reverse Pawl	0104	Yoke Spring	0596	Ball Bearing
0038	Pawl Supporter	0128	Handle Nut Plate Screw		
0039	Anti-Reverse Pawl Spring	0213	Handle Nut Plate		