



Part No.	Description	Part No.	Description	Part No.	Description
BNT0031	Ball Bearing	BNT1465	Clutch Pawl Spring	BNT2250	Line Guide
BNT0042	Line Guide Pawl	BNT1472	Anti-Reverse Pawl	BNT2251	Worm Bushing (A)
BNT0124	Ball Bearing	BNT1602	Key Washer	BNT2252	Worm Shaft
BNT0133	Worm Shaft Retainer	BNT1616	Return Pin Guide Screw	BNT2253	Drive Shaft Cover Screw
BNT0191	Multi-Purpose Screw	BNT1676	Spool Tension Spacer (B)	BNT2254	Drive Shaft Cover
BNT0194	Ball Bearing	BNT1677	Spool Tension Spacer (A)	BNT2255	A-Side Frame
BNT0425	"E" Lock	BNT1678	Spool Tension Spring	BNT2256	Level Wind Guard
BNT0664	Spacer (B)	BNT1692	Handle Nut Plate	BNT2257	Stabilizer Bar
BNT0682	Frame Bar (A) Screw	BNT1892	Cast Control Cap	BNT2258	Thumb Rest
BNT0686	"E" Lock	BNT1938	Idle Gear (C)	BNT2259	Frame Bar (A)
BNT0689	Anti-Reverse Pawl Screw	BNT1940	Frame Nut	BNT2260	Spool Assembly
BNT0770	Handle Nut Plate Screw	BNT1941	Stand Screw	BNT2261	Stand
BNT0797	Handle Nut	BNT1948	Brake Collar	BNT2262	Clutch Button Guide
BNT0799	Friction Washer	BNT1949	I.D. Plate Screw	BNT2263	Quick-Fire II Clutch Button
BNT0810	Drag Washer	BNT2070	Idle Gear (B)	BNT2264	Clutch Button Support Bar
BNT0816	Shaft Washer	BNT2236	Handle Assembly	BNT2265	B-Side Frame
BNT0817	Clutch Cam Retainer Screw	BNT2237	Right Side Plate Screw	BNT2266	B-Side Frame Nut
BNT0820	Pinion Gear	BNT2238	Bush Plate Screw	BNT2267	Worm Bushing (B)
BNT0830	Spacer (optional)	BNT2239	Right Side Plate	BNT2268	Brake Case
BNT1239	Pawl Cap	BNT2240	Return Pin Guide	BNT2269	B-Side Seal
BNT1245	Clutch Bar Support Spacer	BNT2241	Roller Clutch Assembly	BNT2270	Left Side Plate
BNT1289	Star Drag Spacer	BNT2242	Roller Clutch Inner Tube	BNT2271	Left Side Plate Screw
BNT1419	Yoke Spring	BNT2243	A-Side Seal	BNT2272	Left Side I.D. Plate
BNT1455	Drag Spring Washer	BNT2244	Drive Shaft	BNT2292	Star Drag
BNT1456	Drive Gear	BNT2245	Clutch Cam	BNT2293	Right Side Plate Nut
BNT1457	Drive Shaft Washer (B)	BNT2246	Clutch Pawl	BNT2305	Stand Bolt
BNT1458	Anti-Reverse Ratchet	BNT2247	Clutch Plate	BNT2341	Idle Gear (A)
BNT1461	Yoke	BNT2248	Set Plate		
BNT1462	Clutch Cam Retainer	BNT2249	Bearing Retainer		