


SHIMANO®

STELLA®

STL-5000FA



Part No.	Description	Part No.	Description	Part No.	Description
RD0041	Drive Gear Washer	RD8024	Rotor Ring	RD8155	Pinion Worm Gear
RD2298	Spacer	RD8035	Ball Bearing	RD8156	Bail Trip Strike
RD2309	Slider Retainer Screw	RD8040	Gear Cover Screw	RD8157	Drive Gear
RD2409	Worm Shaft Spacer	RD8051	Side Cover Screw (B)	RD8158	Flange Water Proof
RD3538	Spool Support	RD8056	Protector Screw (C)	RD8159	Side Cover
RD3600	Worm Shaft Retainer Screw (B)	RD8059	Protector Screw (D)	RD8160	Oil Shield Cover
RD4675	Oscillating Pawl Cover Screw	RD8117	Drag Knob	RD8161	Oil Cap
RD6008	Set Screw	RD8118	Drag Washers Retainer	RD8162	Handle Shaft Seal
RD6013	Main Shaft Spacer	RD8119	Key Washer	RD8163	Handle Shaft Cover
RD6060	Oscillating Slider Bushing	RD8120	Drag Washer (A)	RD8164	Disc Spring
RD6061	Oscillating Pawl	RD8121	Eared Washer	RD8165	Large Handle Shank Washer
RD6073	Bearing Spacer	RD8122	Drag Click Holder Cover Screw	RD8166	Handle Shaft (Left)
RD6074	Line Roller Bushing	RD8123	Drag Click Holder Cover	RD8167	Handle Shank Screw
RD6075	Roller Bearing Seal	RD8124	Drag Click Holder	RD8168	Handle Shank Assembly
RD6077	Click Pin	RD8125	Drag Washer (B)	RD8169	Handle Knob Adjust Washer
RD6085	Line Roller	RD8126	Drag Click Collar	RD8171	Handle Knob Adjust Washer
RD6109	Spool Washer	RD8128	Ball Bearing	RD8172	Handle Knob Nut
RD6110	Bearing Bushing	RD8129	Main Shaft	RD8174	Handle Knob Screw
RD6148	Oscillating Guide (B)	RD8130	Line Roller Washer	RD8175	Side Cover Screw (C)
RD6216	"O" Ring	RD8131	Bail Trip Lever	RD8176	Oscillating Pawl Cover
RD6225	Nut Lock Screw	RD8132	Bail Trip Cover Spring	RD8177	Oscillating Slider
RD6296	Click Spring	RD8133	Bail Trip Cover	RD8178	Rear Protector
RD6616	Side Cover Screw (A)	RD8134	Bail Arm	RD8179	Rear Shield
RD7786	Ball Bearing	RD8135	Line Roller Screw	RD8180	Worm Shaft Retainer Screw (A)
RD7787	Bail Spring Guide (A)	RD8136	Bail Spring Cover	RD8181	Worm Shaft Retainer
RD7788	Spring Guide (A) Support	RD8137	Rotor Guard	RD8182	Worm Shaft Retainer Washer
RD7801	Ball Bearing	RD8138	Rotor	RD8187	Spool Assembly
RD7827	Handle Screw Cap	RD8139	Bail Hold Support Guard	RD8188	Handle Knob (Round type A)
RD7915	Ball Bearing	RD8140	Bail Assembly	RD8189	Handle Knob I.D. Plate
RD7919	Click Spring	RD8141	Roller Clutch Water Proof Retainer	RD8190	Body
RD7920	Click Pin	RD8142	Roller Clutch Water Proof		
RD7921	Bail Spring	RD8143	Roller Clutch Assembly		
RD7922	Bail Spring Seat	RD8144	Bearing Retainer Screw		
RD7934	Ball Bearing	RD8145	Bearing Retainer	RD8191	Handle Knob Assembly (T type A)
RD7943	Ball Bearing	RD8146	Pinion Gear	RD8567	Left Handle Assembly (T type A 4000)
RD8003	Rotor Nut Lock Plate	RD8147	Friction Ring	RD8568	Right Handle Assembly (T type A 4000)
RD8004	Bearing Water Proof	RD8148	Worm Bushing	RD8569	Left Handle Assembly (Round type A 4000)
RD8005	Ball Bearing	RD8149	Idle Gear	RD8570	Right Handle Assembly (Round type A 4000)
RD8006	Rotor Nut	RD8150	Worm Shaft		
RD8014	Bail Arm Screw	RD8151	Gear Cover	RD8170	Spare Handle Knob (T type A)
RD8015	Bail Arm Screw Collar	RD8152	Gear Cover Seal	RD8173	Spare Handle Knob I.D. Plate
RD8016	Protector Screw (A)	RD8153	Idle Gear (B)	RD8184	Handle Shaft (Right)
RD8022	Bail Hold Support Washer	RD8154	Idle Gear Collar	RD8186	Line Band (L)