



Tc 5/6 PARTS LIST

KEY NO	PARTS NO	PARTS NAME
100	31000133	BODY ASSY.
101	31010017	MAIN SHAFT
102	31020057	BODY FOOT
111	31110004	CLICK PAWL
300	33000072	DRAG KNOB
303	33030006	FIXED PLATE
304	33040014	CLICK PAWL
305	33050018	CLICK PAWL SPRING
314	33140001	SPRING WASHER
315	33150002	DISK BREAK ASSY.
332	33320006	BREAK BLOCK
332-1	33320007	BREAK BLOCK
333	33330002	COMPRESSION SPRING
335	33350001	DRAG CLUTCH PLATE
336	33360002	DRAG KNOB NUT
400	34000121	SPOOL ASSY.
400-1	34000730	SPOOL
403	34030005	CLICK PAWL
404	34040026	HANDLE KNOB
405	34050013	HANDLE KNOB SCREW
408	34080014	SPOOL RETAINER
409	34090001	SPOOL RETAINER SPRING
410	34100063	SPOOL COVER ASSY.
413	34130004	COUNTER BALANCE
416	34160003	ONE WAY BEARING BUSHING
420	34200005	HANDLE KNOB BUSHING
509	35090001	"E" RETAINER
901	29010001	FIXED WASHER
910	0910086	BEARING ASSY.
920	0920056	WASHER
920	0920077	WASHER
920	0920092	WASHER
930	0930080	SCREW
930	0930086	SCREW
930	0930117	SCREW
930	0930525	SCREW
930	09301219	SCREW