


TEAM DAIWA - Z103P



Key No.	Parts No.	Parts Name
1	G03-6801	L/S PLT
2	F57-7901	SET PLT SCREW
3	E16-7101	SET PLT SPRING
4	F57-7802	BRAKE ADJ KNOB
5	B33-9801	BRAKE DIAL RET A
6	F63-7701	BRAKE DIAL WASHER
7	F05-1701	BRAKE CLICK SPRING
8	F61-3401	BRAKE DIAL RET B
9	G01-1901	LEFT SET PLT
10	F71-7702	MAGNET HOLDER
11	351-0906	LEFT SET PLT SCREW
12	B54-3201	MAGNET HOLDER RET RING
13	375-7404	SPACER A
14	375-7411	SPACER B
15	F57-4303	SPACER C
16	F57-7703	BALL BEARING A
17	E21-9701	BEARING RET A
18-26	Z01-2007	SPOOL
27	G00-8801	FRAME
28	G00-9301	CLUTCH LEVER PLT A
29	G00-9501	CLUTCH LEVER
30	G00-9401	CLUTCH LEVER PLT B
31	320-5901	WORM SHAFT RET
32	F65-5501	WORM SHAFT WASHER
33	B71-5601	WORM SHAFT BUSH
34	F83-6501	WORM SHIELD
35	G01-0401	LINE GUIDE
36	121-4212	LINE GUIDE PAWL
37	373-1303	LINE GUIDE WASHER
38	342-4803	PAWL CAP
39	F05-5601	BALL BEARING B
40	G01-0701	WORM SHAFT COLLAR
41	G01-0801	WORM SHAFT
42	G01-1702	STABILIZER BAR
43	G01-1601	FRONT PLT
44	F83-4701	BALL BEARING COLLAR
45	B86-1702	BALL BEARING C
46	F79-3501	CLUTCH CAM
47	G00-9601	YOKE PLT
48	G01-0101	CLUTCH CAM SPRING
49	G02-1301	COLLAR
50	G00-9701	CLUTCH CAM SCREW
51	G00-9801	CLUTCH TRIP PLT
52	371-6903	CLUTCH TRIP PLT WASHER

Key No.	Parts No.	Parts Name
53	320-1403	CLUTCH TRIP PLT RET
54	F79-4801	YOKE
55	G04-7201	YOKE SPRING
56	G12-5601	PINION GEAR
57	E21-9701	BEARING RET B
58	F05-5601	BALL BEARING D
59	G00-8303	R/S PLT
60	G04-0801	R/S PLT SCREW
61	F26-2701	CLICK LEAF SPRING
62	G01-5501	PINION SHAFT
63	B17-5401	SPOOL ADJ CAP METAL
64	B17-5503	SPACER D
65	F83-3901	CAST CONTROL CAP
66	F64-7201	DRIVE SHAFT WASHER A
67	F05-5601	BALL BEARING E
68	G00-9901	DRIVE SHAFT
69	G01-0001	DRIVE SHAFT RET
70	E13-4503	DRIVE SHAFT RET SCREW A
71	G02-1201	DRIVE SHAFT RET SCREW B
72	G01-0201	CLUTCH TRIP PLT SPRING
73	F83-6901	A/R RATCHET
74	E48-9502	DRIVE SHAFT WASHER B
75	G01-1201	WORM SHAFT GEAR
76	G12-5501	DRIVE GEAR
77	F79-6102	EARED WASHER
78	F79-6201	DRAG WASHER A
79	F79-6303	KEY WASHER A
80	F96-7801	DRAG WASHER B
81	B36-0303	KEY WASHER B
82	G01-1401	GEAR SHAFT COLLAR
83	F99-9802	ROLLER CLUTCH
84	F58-2501	BALL BEARING F
85	B55-3801	BEARING WASHER
86	F02-8201	CLICK LEAF SPRING HOLDER
87	F03-2401	CLICK LEAF SPRING
88	150-8901	DRAG SPRING WASHER
89	373-7810	SPACING SLEEVE
90	G01-1501	STAR DRAG
91	F57-6601	FRICITION WASHER
92	F83-7201	HANDLE
93	B43-3601	HANDLE NUT
94	F57-7202	HANDLE NUT RET PLT
95	G26-2301	PLT