



T211R / T209R / T208R / T206R PARTS LIST



Key NO.	Parts NO.	Parts name
1	2S2-014-01	SPOOL CAP
2	2YE-001-01	SPOOL RELEASE LEVER ASSY
3	2Q3-088-01	SPOOL RELEASE LEVER SPRING
4	2Z1-013-05	610-3 BALL BEARING
5	2S1-226-01	SPOOL
6	2E2-045-01	X20M-050 SCREW
7	2C3-032-02	HANDLE KNOB RING
8	2H4-037-02	HANDLE KNOB
9	2C3-044-01	HANDLE KNOB RING
10	2E0-020-02	HANDLE KNOB SCREW
11	2E2-052-02	F26M-080 SCREW
12	2R8-070-01	BALANCER
13	2E2-014-02	F26M-060 SCREW
14	2YZ-013-01	ONE-WAY CLUTCH BEARING ASSEMBLY
15	2E4-009-01	DRAG WASHER RETAINER
16	2M3-090-02	SPOOL SHAFT
17	2W1-186-01	062-100 WASHER
18	2C1-092-01	SPACER
19	2A4-061-01	ONE-WAY CLUTCH INNER TUBE
20	2Z1-008-05	1020-5 BALL BEARING
21	2YD-071-01	BRAKE DISC ASSY
22	2P1-054-01	CLICK PIN
23	2Q2-019-01	CLICK PIN SPRING
24	2F8-092-01	CLICK HOLDER
25	2W1-008-01	048-080 WASHER
26	2B1-100-04	BODY

Key NO.	Parts NO.	Parts name	
27	2E3-054-02	NUT	
28	2L1-017-01	SPRING WASHER	
29	2W1-187-01	072-256 WASHER	
30	2L1-018-01	SPRING WASHER	
31	2D1-054-02	DRAG KNOB	
32	2E0-041-01	X30M-045 SCREW	
33	2F8-091-01	STAND	
34	2E0-030-01	STAND SCREW	
35	2YT-326-01	SPOOL TOTAL ASSEMBLY	
36	2YB-177-02	BODY TOTAL ASSEMBLY	
T208R	1	2S2-014-02	SPOOL CAP
SPECIAL	5	2S1-228-01	SPOOL
PARTS	26	2B1-102-04	BODY
	35	2YT-328-01	SPOOL TOTAL ASSEMBLY
	36	2YB-181-02	BODY TOTAL ASSEMBLY
T209R	1	2S2-014-03	SPOOL CAP
SPECIAL	5	2S1-230-01	SPOOL
PARTS	26	2B1-104-04	BODY
	35	2YT-330-01	SPOOL TOTAL ASSEMBLY
	36	2YB-185-02	BODY TOTAL ASSEMBLY
T211R	1	2S2-014-04	SPOOL CAP
SPECIAL	5	2S1-232-01	SPOOL
PARTS	26	2B1-106-04	BODY
	35	2YT-332-01	SPOOL TOTAL ASSEMBLY
	36	2YB-189-02	BODY TOTAL ASSEMBLY

S211R / S209R / S208R / S206R PARTS LIST



Key NO.	Parts NO.	Parts name
1	2S2-010-03	COOLING SHIELD
2	2YE-001-01	SPOOL RELEASE LEVER ASSY
3	2Q3-088-01	SPOOL RELEASE LEVER SPRING
4	2Z1-013-05	610-3 BALL BEARING
5	2S1-227-01	SPOOL
6	2E2-045-01	X20M-050 SCREW
7	2C3-032-02	HANDLE KNOB RING
8	2H4-048-01	HANDLE KNOB
9	2E0-020-02	HANDLE KNOB SCREW
10	2E2-052-02	F26M-080 SCREW
11	2R8-064-02	BALANCER
12	2E2-014-02	F26M-060 SCREW
13	2YZ-013-01	ONE-WAY CLUTCH BEARING ASSEMBLY
14	2E4-009-01	DRAG WASHER RETAINER
15	2M3-090-02	SPOOL SHAFT
16	2C3-045-01	BUSH
17	2A4-061-01	ONE-WAY CLUTCH INNER TUBE
18	2Z1-008-05	1020-5 BALL BEARING
19	2YD-071-02	BRAKE DISC ASSY
20	2P1-054-01	CLICK PIN
21	2Q2-019-01	CLICK PIN SPRING
22	2F8-092-01	CLICK HOLDER
23	2W1-008-01	048-080 WASHER
24	2B1-100-05	BODY
25	2E3-054-02	NUT

Key NO.	Parts NO.	Parts name	
26	2L1-017-01	SPRING WASHER	
27	2W1-187-01	072-256 WASHER	
28	2L1-018-01	SPRING WASHER	
29	2D1-055-02	DRAG KNOB	
30	2E0-041-01	X30M-045 SCREW	
31	2F8-091-02	STAND	
32	2E0-030-01	STAND SCREW	
33	2YT-327-01	SPOOL TOTAL ASSEMBLY	
34	2YB-178-02	BODY TOTAL ASSEMBLY	
35	2W1-087-01	060-080WASHER	
S208R	1	2S2-010-04	SPOOL CAP
SPECIAL	5	2S1-229-01	SPOOL
PARTS	24	2B1-102-05	BODY
	33	2YT-329-01	SPOOL TOTAL ASSEMBLY
	34	2YB-182-02	BODY TOTAL ASSEMBLY
S209R	1	2S2-010-05	SPOOL CAP
SPECIAL	5	2S1-231-01	SPOOL
PARTS	24	2B1-104-05	BODY
	33	2YT-331-01	SPOOL TOTAL ASSEMBLY
	34	2YB-186-02	BODY TOTAL ASSEMBLY
S211R	1	2S2-010-06	SPOOL CAP
SPECIAL	5	2S1-233-01	SPOOL
PARTS	24	2B1-106-05	BODY
	33	2YT-333-01	SPOOL TOTAL ASSEMBLY
	34	2YB-190-02	BODY TOTAL ASSEMBLY