



Vi-200R. PARTS LIST

KEY NO	PARTS NO	PARTS NAME	KEY NO	PARTS NO	PARTS NAME
100	41000402	MAIN BODY ASSY.	705	47050008	TRANSMISSION GEAR
105	41050003	WORM SHAFT BUSHING	705-1	47050009	TRANSMISSION GEAR
117	41170001	RETAINER NUT	711	47110032	GUIDE SLIDE BASE ASSY.
119	41190032	BODY COVER	712	47120007	WORM SHAFT
200	42000228	HANDLE SIDE PLATE	713	47130003	LINE GUIDE PAWL CAP
202	42020002	RATCH	715	47150002	LINE GUIDE PAWL
206	42060003	STOPPER CAP	720	47200003	DRIVE GEAR SHAFT BUSHING
226	42260001	CONTROL PIN	721	47210002	DRIVE GEAR SHAFT BUSHING
300	43000151	VICE SIDE PLATE	721-1	47210003	DRIVE GEAR SHAFT BUSHING
302	43020004	WASHER	725	47250001	TRANSMISSION GEAR PIN
302-3	13020014	WASHER	800	48000005	CLUTCH SHAFT
316	43160013	FIXED PLATE BUTTON ASSY.	801	48010004	CLUTCH SHAFT SPRING
316-1	43160020	FIXED PLATE BUTTON	802	48020068	CLUTCH BAR
400	44000716	SPOOL ASSY.	804	48040004	CLUTCH SLIDER
401	44010008	SPOOL CLICK GEAR	804-1	48040008	CLUTCH SLIDER
412	24120038	SPOOL BUSHING	805	48050007	PINION GEAR YOKE
500	45000086	HANDLE ARM ASSY.	806	48060002	YOKE SPRING
516	45160024	HANDLE NUT RETAINER	806-1	48060004	YOKE SPRING
600	46000050	CAST CONTROL CAP	807	48070006	YOKE BRAKED PLATE
603	46030003	O RING	808	48080004	YOKE BRAKED PLATE SPRING
608	46080002	DRAG WASHER RETAINER	812	48120003	BRAKED PLATE HOLDER
609	16090009	DRAG SPRING WASHER	910-3	0910170	BALL BEARING
610	16100037	DRAG WASHER	920-1	0920105	WASHER
612	16120029	KEY WASHER	920-4	0920292	WASHER
612-2	26120056	KEY WASHER	920-5	0920014	WASHER
615	46150051	STAR DARG	930-1	0930011	SCREW
618	16180002	WASHER	930-9	0930982	SCREW
700	47000019	DRIVE GEAR	930-14	0930547	SCREW
701	47010009	DRIVE GEAR SHAFT	930-16	0930763	SCREW
702	47020047	PINION GEAR ASSY.	930-19	0930704	SCREW
703	47030017	WORM SHAFT GUARD	930-33	0930044	SCREW
704	47040012	LINE GUIDE SUPPORT BAR	900-1	29000001	E RETAINER