




Key No.	Parts No.	Parts Name	Key No.	Parts No.	Parts Name
2-9	G10-7401	SPOOL	30	E37-0003	TRIGGER SCREW
2-9	G17-1001	SPOOL (EXTRA)	31	F31-0511	BAIL SPRING COVER
1	F32-2108	DRAG KNOB	32	E36-4202	BAIL HOLDER COVER SCREW
2	171-7701	DRAG WASHER RET	33	F31-0611	BAIL HOLDER COVER
3	E13-6003	DRAG WASHER	34	E49-2401	A/R RATCHET
4	373-3603	EARED WASHER	35	F19-6301	A/R PAWL SPRING B
5	E46-7201	KEY WASHER	36	F19-6201	A/R COLLAR
7	B07-5304	CLICK PAWL	37	L03-6601	BALL BEARING B
8	E40-3101	CLICK SPRING	38	E51-9801	PINION GEAR
9	320-5901	CLICK RET	39	G04-9102	BODY
10	E39-8000	SPOOL WASHER A	40	L00-1801	A/R PAWL SCREW
11	E46-7101	SPOOL WASHER B	41	F19-5301	A/R PAWL
12	270-6501	CLICK GEAR	42	L01-4302	A/R PAWL COLLAR
13	F99-0601	MAIN SHAFT	43	L00-1501	A/R PAWL SPRING A
14	341-9201	ROTOR NUT	44	F19-5201	A/R CAM SPRING
15	F31-0116	ROTOR	45	F98-9301	A/R CAM
16	320-5901	BAIL ARM SCREW RET	46	F98-9201	A/R LEVER
17	B67-9304	LINE ROLLER SCREW	47	F98-9401	A/R LEVER SCREW
18	E49-3501	BAIL ARM SCREW	48	E03-7801	BEARING RET SCREW
19	F61-9301	BAIL ARM	49	F67-7401	OSC GEAR
20	F44-6302	ROLLER COLLAR	50	F98-9601	OSC SLIDER
21	F44-6202	LINE ROLLER WASHER	51	351-0315	OSC SLIDER SCREW
22	F05-5601	BALL BEARING A	52	631-6901	BALL BEARING C
23	F47-2401	LINE ROLLER	53	F17-0001	DRIVE GEAR
24	G10-7201	BAIL	54	373-7808	DRIVE GEAR WASHER
25	B84-2102	BAIL HOLDER SCREW	55	F98-9703	SIDE COVER
26	F12-8901	BAIL SPRING	56	E15-8602	SIDE COVER SCREW
27	E45-1601	BAIL TRIP LEVER	57	G04-9201	HANDLE
28	F18-0011	TRIGGER LEVER	58	F02-0201	HANDLE WASHER
29	E36-9901	TRIGGER SPRING	59	F03-5605	HANDLE SCREW